

Burgess A P

METAL CEILING SYSTEMS

Installation of Crosslock Tegular System

1. Using a laser, or equivalent, determine ceiling level and secure perimeter trim (GT119) to the wall at 450mm maximum centres.
2. Cut lengths of either suspension angle (GT114) or suspension wire to suit suspension depth, ensuring sufficient length for fixing.
3. Setting out from the centre of the room, secure hangers at 1500mm maximum centres to the structural soffit using fixings approved by the Architect and determined by load and safety factor considerations. The first hangers are to be no more than 450mm from the wall. Where possible, not less than half tiles should be used at perimeters.
4. To achieve a 600 x 600mm module install Main Runners at 1200mm centres using M6 or equivalent fixings to angle hangers. Wire hangers to have a minimum of 3 turns to form a tight coil.
5. Interlock 1200mm cross tees between main runners at 600mm centres and 600mm cross tees centrally between them. Ensure extruded sleeves are correctly located on intersection block at joins to maintain alignment.
6. Tiles can now be offered into place within the grid.
7. Cut perimeter tiles must be retained using wedges (GT120) spaced at 300mm maximum centres.

Please note

As manufacturers only, Burgess Architectural Products Ltd. cannot be held responsible for the installation of the ceiling.

Site conditions, special applications, services integration etc. may require variations to the above instructions, which are given purely as a general guide.

Ceilings to be installed in accordance with AIS (Association of Interior Specialists) Guide No.1, Good practice For the Installation of Suspended Ceilings and BS 8290: Part 3: 1991, Code of practice for installation and maintenance.